

品名: 4K儿童相机说明书-简英
 材质: 128g 铜版纸
 工艺: 双面印 风琴折 过油
 尺寸: 65*90mm

中文简体

INSTRUKCJA C7

Proszę przeczytać ją uważnie przed użyciem produktu!

- 1 Wł./wyl. aparat
- 2 Głośnik
- 3 Ostrona obiektywu
- 4 Obiektyw
- 5 Gniazdo karty microSD
- 6 USB-C
- 7 Reset
- 8 Mocowanie smyczy
- 9 Obiektyw
- 10 Mikrofון
- 11 Powrót
- 12 Góra
- 13 Dół
- 14 Potwierdzi
- 15 Dioda kontrolna
- 16 Miğawka
- 17 Zmiana obiektywu

Opis funkcji

Zdjęcia:
W menu głównym wybierz następnie naciśnij [OK] aby wejść w tryb fotograficzny. Naciśnij przycisk migawki, aby zrobić zdjęcie.

Wideo:
W menu głównym wybierz następnie naciśnij [OK] aby wejść w tryb wideo. Naciśnij przycisk migawki, aby rozpocząć nagrywanie.

Filtry / ramki zdjęć:
W menu głównym wybierz następnie naciśnij [OK] aby wejść w tryb. Wybierz filtr / ramkę i naciśnij migawkę, aby zrobić zdjęcie.

Ust. fotografowania:
W menu głównym wybierz następnie naciśnij [OK] aby wejść w tryb. Ustaw: Auto Focus, tryb fotografowania, timer, scena, balans bieli, tryb ISO.

Ustawienia:
W menu głównym wybierz następnie naciśnij [OK] aby wejść w ustawienia. Maszco ustawić m.in.: Język, datę i godzinę, formatowanie karty, dźwięk, rozdzielczość.

Album:
W trybie albumu wybierz plik wideo. Naciśnij [OK] aby utworzyć.

Ustawianie wideo:
W trybie albumu wybierz plik wideo. Naciśnij [OK] aby utworzyć.

Usuwanie plików:
W trybie albumu wybierz plik, który chcesz usunąć. Naciśnij i przytrzymaj [OK] aby usunąć wybrany plik.

Wygaszacz ekranu:
Naciśnij [OK] aby wyłączyć ekran. Naciśnij i przytrzymaj [OK] aby włączyć i wyświetlić funkcje aparatu.

Formatowanie karty:

Formatowanie karty microSD usuwa wszystkie zdjęcia oraz filmy z urządzenia. Pamiętaj! działanie to jest nieodwracalne.

W menu głównym wybierz [OK] następnie naciśnij [OK] aby potwierdzić operację. Wybierz formatowanie karty, następnie naciśnij [OK] aby ponownie uruchomić aparat.

Reset:
Jeśli wyświetlacz LCD oraz przyciski przestają reagować - lekko wciśnij przycisk RESET (możesz użyć do tego np. spinacza biurowego). Wybierz formatowanie karty, następnie naciśnij [OK] aby ponownie uruchomić aparat.

Ładowanie:
Gdy bateria jest na niskim poziomie lub urządzenie wyłącza się automatycznie - podłącz kabel do aparatu oraz ładowarki (funkcja szybkiego ładowania nie jest obsługiwana). Podczas ładowania dioda świeci się na czerwono i zmienia kolor na zielony, gdy urządzenie się naładuje.

Instalacja karty microSD:
1. Proszę włożyć kartę do gniazda odpowiednią stroną. Przy wymianianiu karty nacisnąć delikatnie kartę microSD, a następnie wyjąć z gniazda. Proszę NIE wkładać, ani wyciągać karty podczas pracy urządzenia, aby uniknąć uszkodzenia aparatu lub karty pamięci.
Karta musi mieć co najmniej 10 Mbasę prędkości (min. zapis do 10MB/s).
 2. Urządzenie ustaw kartę jako priorytetowe urządzenie pamięci masowej. Dane znajdujące się na karcie mogą nie zostać poprawnie odczytane przez urządzenie. Zaleca się skopiowanie ich przed umieszczeniem karty w aparacie.
 3. Jeśli karta nie wykrywana przez urządzenie, proszę sformatować ją lub użyć innej karty microSD.

Specyfikacja:

Model	C7
Wyświetlacz	2.4"
Funkcje	Foto / wideo
Pojemność baterii	1200 mAh
Czas pracy	ok. 2 godziny
Czas ładowania	ok. 3-3.5 godziny
Max. poj. karty microSD	32GB
Waga	100.8 g
Napięcie ładowania	5V / 1A

Środki ostrożności:

Akumulator należy ładować pod nadzorem dorosłych.

- Regularnie sprawdzaj integralność zabawki. Jeśli są jakiegokolwiek uszkodzone części, przestań go używać i trzymaj z dala od dzieci.
- Ten aparat wykorzystuje wbudowany akumulator polimerowy 3.7 V/1200mAh, którego nie można zdemontować.
- Baterii nie można ładować za pomocą zasilacza powyżej zalecanego napięcia. Zalecana specyfikacja ładowarki: DCSV / 1A.
- Urządzenie może być używane i ładowane tylko pod nadzorem osoby dorosłej. Gniazda zasilania nie mogą być zwarte.
- Urządzenie powinno być wyłączone podczas ładowania.
- Nie używać urządzenia w pobliżu źródła ognia.
- Nie przechowywać w miejscu w pobliżu ognia, wysokiej temperatury oraz wysokiej wilgotności.
- Gdy nie używasz urządzenia przez długi czas, proszę w pełni naładować akumulator przed wyłączeniem urządzenia.

Urządzenie nie może być używane przez dzieci w wieku poniżej 3 lat!

Karta gwarancyjna

Nazwisko: _____

Imię: _____ TEL: _____

Adres: _____

Model produktu: _____

Miejsce zakupu: _____

Data zakupu: _____

Opis usterki: _____

英文

User Manual

Please read the instruction carefully before using the product!

- 1 ON/OFF key
- 2 Speaker
- 3 Lens protective cover
- 4 Lens
- 5 TF card slot
- 6 Type-C interface
- 7 Reset button
- 8 Lanyard hole
- 9 Lens
- 10 Voice Mouth
- 11 Return key
- 12 Up key
- 13 Down key
- 14 OK key
- 15 Indicator light
- 16 Screen
- 17 Shutter button
- 18 Before/after lens switch key

Function Description:

Photo:
Main menu, select photo Short press [OK] to enter the photo mode Short press [Shutter button] to shoot En otras interfaces, Short press [OK] to enter the photo mode

Video:
Main menu, select video Short press [OK] to enter the video mode Short press [shutter key] to record

Fun shooting:
Main menu, select fun shooting Short press [OK] to enter photo ID mode Short press [Shutter button] to shoot

Shooting settings:
Main menu, select shooting settings Short press [OK] to enter shooting setting mode Set auto focus, triple shooting, timer shooting, Scene, white balance, ISO mode

Settings:
Main menu, select settings Short press [OK] to enter setting mode Set automatic shutdown, sound, language, pixel Date and time, formatting and other modes

Album:
Main menu, select album Short press [OK] to enter album mode Press up/down keys to view

Video playback:
In the album interface, select record video Short press [OK] to play video

Delete Files:
In the album interface, select the file to delete Long press [OK key] to delete

screen protector:
Short press [On key] to turn on the screen saver Long press [ON key] to switch machine function

Formatting:

Formatting the TF card and delete all the photos and videos in the camera. **(Please note that this action cannot be irrevocable.)** Long press [Menu] to enter the menu and choose whether to format the TF card, and then click [Confirm] key to confirm.

Reset:
If the LCD display is frozen and the buttons are not working, press the [Reset] lightly with an ejector pin. Press the [ON/OFF] to restart the camera.

Charging:
When the battery is low or the camera automatically shuts down. Use the adapter to recharge the battery. Fast charge function is not supported. The indicator light is red when charging and it turns green when the battery is full.

1. Insert the TF card into the slot in the right direction until the TF card is fixed. Gently press the TF card to eject. Please do not remove the TF card when the camera is turned on to avoid damage to the files!

TF card must be a card with high speed over C10.

2. Please pay attention to the installation direction of TF card. Install the card from the wrong side may cause damage to the card, the slot, and the camera.

3. The camera will set the TF card as the priority storage device. The original data in the TF card may not be identified. So please backup the files before installation.

4. If the TF card is incompatible with the machine, please format the TF card or use a different TF card.

Parameters:

Display	2.4"
Functions	photo / video
Battery Capacity	1200mAh
Using Time	About 2 hours
Charging Time	About 3.0-3.5 hours
Video time	About 2.0 hours
Maximum support for TF Card	32G
Weight of Camera	100.8g
Charging Voltage	5V/1A

Battery Operations & Attention

This camera uses a built-in 3.7V/1200mAh polymer battery, which cannot be disassembled and replaced. Please contact the retailer for repair in case of fault. the battery should be recharged under the supervision of adults. The camera should be turned off while

Maintenance:

The electrical components of the product must not be placed in water or humid conditions. use a dry rag to wipe stains from the surface when cleaning. Do not let children play with camera that is disassembled, damaged, or modified to avoid accidental swallowing and suffocation!

Warranty Certificate

Warranty Clause
Thank you for supporting our products. Your camera is backed up with one year replacement warranty Australian wide.

Please fill out the warranty card and keep it as a certificate of warranty. The warranty period of one year applies from the date of purchase. Attention: the following items are not covered by the warranty:
 1. Damaged due to improper use or maintenance by the customer.
 2. Damage caused by disassemble or modification of the product.
 3. Using incompatible parts that is not manufactured by our company.
 4. Normal wear and tear.
 5. Damage caused by abusive use.

We provide a paid repair service in addition to the warranty. Please send the product together with the warranty card and invoice with the date of purchase. Please consult your retailer or official customer service for any questions about the warranty.

Product Name / Type: _____ Date of Purchase: _____
 Place of Purchase: _____ Contact Number: _____

Warranty Date	Default and Treatment	Completion Date	Customer Signature

Customer Retention