

品名: K27 打印相机 说明书-简英
 材质: 128g 铜版纸
 工艺: 双面印 过油
 尺寸: 70*90mm

中文简体

KIDS PRINT CAMERA

Instrukcja

Proszę przeczytać ją uważnie przed użyciem produktu!

- 1 Obiektyw
- 2 Lampa błyskowa
- 3 Główny
- 4 Drukarz
- 5 Wybór obiektywu
- 6 Uch. na smycz
- 7 Obiektyw
- 8 Mikrofon
- 9 Góra
- 10 Cofnij
- 11 Dioda
- 12 Ustawienia
- 13 Piłwerdz
- 14 Ekran
- 15 Uch. na smycz
- 16 Slot microSD
- 17 Slot USB-C
- 18 Góra
- 19 RESET

Montaż papieru termicznego:

Opis funkcji:

Wł./Wył. aparatu / Wybór obiektywu
 Naciśnij i przytrzymaj przycisk [ON/OFF] [1], aby włączyć/wyłączyć aparat. Krótkie naciśnięcie [2] przelacza obiektyw.

Robienie zdjęć / Time lapse
 Naciśnij przycisk [3], aby zrobić zdjęcie. Wejdź w ustawienia [4], aby włączyć funkcję time lapse.

Filtry / Ramki zdjęć
 W trybie fotografowania naciśnij [5], aby przelaczyć ramki. Naciśnij [6], aby zrobić zdjęcie. Naciśnij [7], aby wejść w tryb wideo. Naciśnij [8], aby wejść w tryb filtrów. Naciśnij [9], aby zrobić zdjęcie.

Drukowanie zdjęć
 W trybie fotografowania naciśnij [10], aby wejść w tryb drukowania. Naciśnij [11], aby zrobić wydruk. W podglądzie albumu wybierz zdjęcie do wydrukowania, następnie naciśnij [12], aby wydrukować zdjęcie.

Albumy / Powrót
 W trybie fotografowania naciśnij [13], aby wejść w tryb albumu. Naciśnij [góra] / [dół], aby przeglądać zdjęcia. Naciśnij [14], aby wrócić w tryb fotografowania.

Nagrywanie wideo / Odtwarzanie
 W trybie fotografowania naciśnij i przytrzymaj [5], aby wejść w tryb wideo. Naciśnij [6], aby rozpocząć nagrywanie. W albumie zdjęć wybierz plik wideo i naciśnij [7], aby otworzyć nagranie.

Lampa błyskowa
 Naciśnij [15], aby włączyć / wyłączyć lampę błyskową. Naciśnij [16], aby wejść w ustawienia. Możliwe tryby: włączona, wyłączona, światło stałe.

Ustawienia
 Naciśnij [12], aby wejść w tryb konfiguracji. Możesz ustawić m.in. intensywność wydruku, rozmiar obrazu, time lapse, datę i godzinę, dźwięk, tryb lampy błyskowej, język oraz sformatować kartę pamięci.

Usuń plik:
 Na ekranie albumu wybierz plik, który chcesz usunąć. Następnie naciśnij [17], aby wejść w ekran usuwania i naciśnij [18], aby potwierdzić usunięcie pliku.

Formatowanie:
 Formatowanie karty microSD usuwa wszystkie zdjęcia oraz filmy z urządzenia. Pamiętaj! działanie to jest nieodwracalne.

Naciśnij i przytrzymaj [19], aby wejść do menu. Wybierz, czy sformatować kartę, a następnie naciśnij [20], aby potwierdzić formatowanie karty.

Reset:
 Jeśli wyświetlacz LCD oraz przyciski przestają reagować - lekko wcisnij przycisk RESET (możesz użyć do tego np. spinacza biurowego) Następnie naciśnij [18], aby ponownie uruchomić aparat.

Ładowanie:
 Gdy bateria jest na niskim poziomie lub urządzenie wyłącza się automatycznie - podłącz kabel do aparatu oraz ładowarki (funkcja szybkiego ładowania nie jest obsługiwana).

Podczas ładowania dioda świeci się na czerwono i gaśnie gdy urządzenie się naładuje. Podczas użytkowania dioda świeci zawsze na niebiesko.

Instalacja karty microSD oraz środki ostrożności:
 Proszę włożyć kartę do gniazda odpowiednią stroną. Przy wyjmowaniu karty nacisnąć delikatnie kartę microSD, a następnie wyjąć z gniazda.

Proszę NIE wkładać, ani wyciągać karty podczas pracy urządzenia, aby uniknąć uszkodzenia aparatu lub karty pamięci.

Specyfikacja:
 Wyświetlacz: 2.0"
 Rozmiar papieru: 57x25 mm
 Pojemność baterii: 1400mAh/3.7V polimerowa
 Czas użytkowania: ~4h
 Czas ładowania: ~2h
 Czas nagrywania: ~2.5h
 Maksymalna poj. karty microSD: 32GB
 Waga: 181.8g
 Napięcie ładowania: 5V/1A

Środki ostrożności:

- Regularnie sprawdzaj integralność zabawki. Jeśli są jakies uszkodzone części, przestań go używać i zrzymaj z dala od dzieci.
- Wbudowany akumulator może być używany i ładowany tylko pod nadzorem osoby dorosłej.
- Nie używaj urządzenia w pobliżu źródła ognia.
- Nie przechowuj w miejscu w pobliżu ognia, wysokiej temperatury oraz wysokiej wilgotności.
- Przycisk zasilania musi być wyłączony po każdym użyciu.
- Gdy nie używasz urządzenia przez długi czas, proszę w pełni naładować akumulator przed wyłączeniem urządzenia.

Urządzenie nie może być używane przez dzieci w wieku poniżej 3 lat!

Konserwacja:
 Nie zanurzaj w wodzie ani nie umieszczaj w wilgotnym środowisku. Zwróć uwagę na czyszczenie i pyłoszczelność, wycieraj suchą szmatką.

Zestaw zawiera:

- Aparat;
- Kabel zasilający;
- Trzy rolki papieru termicznego;
- Smycz;
- Zestaw naklejek;
- Instrukcję obsługi.

英文

KIDS PRINT CAMERA

User Manual

Please read the instruction carefully before using the product!

Key Description:

- 1 Lens
- 2 Fill light
- 3 Speaker
- 4 Fill light switch key
- 5 Print paper slot
- 6 On/Off key
- 7 Lens switch key
- 8 Shutter key
- 9 Lens
- 10 MIC
- 11 Up key
- 12 Back key
- 13 Down key
- 14 Indicator light
- 15 Set key
- 16 OK key
- 17 Print key
- 18 Screen
- 19 Lanyard hole
- 20 TF card slot
- 21 Type-C interface
- 22 Reset key

Mounting of print paper:

Functional description:

On/off key / Lens switch key:
 Press and hold the [ON/OFF key] [1] to switch the camera on/off. Short press [On/Off key] [2] for front/rear lens switch.

Photo taking/ Time lapse:
 Short press [Shutter key] [3] for shooting mode. Press the [Set key] [4] to enter the setting mode. Turn on the time-lapse function in the menu.

Filters / Cartoon frames Shooting:
 In shooting mode Press the [Up key] [5] to switch cartoon frames. Short press [Shutter key] [6] to shoot. Press the [Down key] [7] to enter filter mode. Short press the [Shutter key] [8] to shoot.

Print shooting / Album printing:
 In shooting mode Press the [Print key] [16] to start the print mode. Press the [Shutter key] [8] to take a print. In the album screen, select the photo to be printed. Press the [Print key] [16] to print the photo.

Albums / Back:
 In shooting mode Short press [Back key] [12] to enter album mode. Press the up/down key to view In other modes Short press [Back key] [12] to return to function.

Video recording / Playback:
 In shooting mode Press and hold the [Shutter key] [6] to enter video mode. Short press [Shutter key] [6] to record video. In the album screen, select the video file. Press [OK key] [15] to play the video.

Fill light mode:
 Short press the [Fill light on/off key] [15] to turn on/off the fill light. Fill light mode: off, on, constant light.

Menu settings:
 Short press the [Setup key] [12] to enter the setup mode. Set the print intensity, image size, time-lapse, continuous shooting, date label, sound language, and Formatting mode.

Delete document:
 In the album screen, select the file you want to delete. Press the [Set key] [4] to enter the delete screen. Press the [OK key] [15] to delete.

Formatting:
 Formatting the TF card and delete all the photos and videos in the camera. (Please note that this action cannot be irrevocable.) Long press [Menu] to enter the menu and choose whether to format the TF card, and then click [OK key] to confirm.

Reset:
 If the LCD display is freezing and the buttons are not working, Press the [Reset] lightly with an ejector pin. Press the [ON/OFF] to restart the camera.

Charging:
 When the battery is low or the camera automatically shuts down. Use the adapter to recharge the battery: Fast charge function is not supported. When charging, the indicator light is red when charging and is non-illuminated when fully charged. When in use, the indicator light is always on blue.

TF Card Installation And Precautions:
 1. Please insert the TF card into the TF card slot in the correct direction until the TF card is fixed in the slot. When removing the TF card, please gently press down the TF card, and then take it out after the TF card is ejected. The TF card must be a high-speed card above C10 to be used. Please do not plug or unplug the TF card while the machine is working, so as to avoid damage to the machine and the TF card.

Parameters:
 Display: 2.0"
 Paper size: 57x25mm
 Battery capacity: 1400mAh
 Usage time: About 4.0 hours
 Charging time: About 2.0 hours
 Recording time: About 2.5 hours
 Maximum support for TF Card: 32G
 Camera weight: 181.8g
 Charging voltage: 5V/1A

Precautions:

- Regularly check the integrity of the toy. If there are any obvious damaged parts, please stop using it and keep it away from children. Do not let children play with disintegrated, damaged or deformed toys to avoid accidental swallowing, suffocation and other hazards.
- The built-in non-removable battery can only be used and charged under the supervision of an adult;
- When children are playing, please do not approach the fire source;
- Do not store in a place near fire, high temperature and humidity;
- If you find that the speed is slow or abnormal, please charge it in time;
- The power switch must be turned off after each use;
- When not using the machine for a long time, please fully charge the battery before turning off the power switch.

Maintenance:
 Do not immerse in water or place in a humid environment; Pay attention to cleaning and dustproof, wipe with a dry cloth.

The set includes:

- Camera.
- Power cable.
- Three rolls of thermal paper.
- Lanyard.
- Stickers.
- User manual.